



**Build  
Faster**

## **Tedlar Patching**

This document applies to the application of the Tedlar Film and decal adhesive patch. This patch offers a simple and convenient method of repairing small cuts and holes in Premium Tedlar coated membrane.

### Required Materials

Tedlar Film Patch (4"x12") or Color Matched Decal (8 ½" x 11")

Utility knife

Tape Measure

Isopropyl Alcohol

Cleaning Rags

Safety equipment to comply with local and/or federal OSHA regulations

Step One: Clean the surface of the membrane with isopropyl alcohol.

Step Two: Patching is accomplished on the exterior (smooth side) of the membrane. Measure the length of the cut to be repaired. Cut a length of the patching film 4" longer than the cut.

Step Three: Peel the backing from the patch and center over the cut. Apply gentle pressure to the perimeter of the patch. Do not apply pressure directly over the cut as this will result in a 'puckered' look.

NOTE: For larger cuts (over 6" in length) contact your Sprung Sales Representative for